1. Install special tool P10 in the cylinder head together with the corresponding valve, spring retainer, and keepers.

Installed length for	41.0 mm	
intake valve springs	1.614 in.	
Installed length for	40.0 mm	
exhaust valve springs	1.575 in.	




Fig. 6

- 2. Adjust with shims until the correct length is obtained.
- 3. Install valve springs so that the closely wound coils are nearest the cylinder head and rest on the steel washer (Fig. 7).




Fig. 7

- a = Installed lengthb = Steel washer
- c = Shims

Lower Air Channel

In order to increase the flow of cooling air of the 1600 S-90 engine, a specially designed lower air channel having two outlet flaps and an intake funnel for the fan housing have been incorporated in the cooling system.




Fig. 8